

SK-3

Blocking At Rim Joist

Existing
Rim
Joist

PRESSURE TREATED
2x4 STUDS AS LONG
AS IS PRACTICAL

Pre-drill holes, preset
gal. deck screws, 3" min

INTERIOR
FINISHES

MORTAR

Screw ceiling framing
to block
between rafters

Fill gap w/ spray foam or
fiberglass insulation

