

BEND FLASHING UP AT END TO ENSURE CONTACT WITH SADDLE. WRAP EDGE OF FLASHING WITH ROOFING PAPER TO PREVENT SQUEAKING. PACK SADDLE WITH MORTAR. SCREW TO WOOD FLOORING

