



1 1/2" STUD WALL

3 5/8" STUD WALL HELD OUT TO FIT ROOF DRAINS FROM BRFL SETBACK

INSERT 1" SEMI RIGID FIBERGLASS BEHIND DRAIN LINE COMPRESS AS NEEDED.

FILL SOLID w/ MORTAR

3 5/8" - 3" PIPE

4 1/2" - 4" PIPE

4" Ø PIPE COLUMN CENTER ON BEAM BELOW & IN WALL ± 4" IN FROM OUTER WALL SURFACES.

WRAP IN SELF ADHERING W/P MEMBRANE, OVER LAP 6" INSTALL DRAIN MAT BETWEEN COLUMN & EXTERIOR W/ THE OF MASONRY COMPRESS AS NEEDED

LINE OF STEEL BEAM BELOW

DRAINAGE MAT